


REPLACEMENT PARTS - MODEL RM4040 and RM4040B

CORDLESS CHAIN SAW

PPN 41AL40VG983 and 41AL40VB983

Item	Part No.	Description	* Optional Items
1	49MA40AQ983	4 Ah Lithium-Ion Battery*	* 49MA50AQ983 5 Ah Lithium-Ion Battery
2	49MA40VQ983	Charger*	

* Not included in the initial purchase of model RM4040B



REPLACEMENT PARTS - MODEL RM4040 and RM4040B

CORDLESS CHAIN SAW

PPN 41AL40VG983 and 41AL40VB983

Item	Part No.	Description	Item	Part No.	Description
1	795-00321	Guide Bar	4	AO5Y1010001R	Chain Tension / Bar Cover Assembly
2	713-05074	Saw Chain	5	J0150000990R	Clip
3	QO3YC950ZN7R	Scabbard	6	J3660000017R	Drive Sprocket

